



QUICK START

POLY STUDIO E70 CAMERA **DISPLAY MOUNT**







(2) M4 × 16 mm Screw





(2) M8 Lock Washer

(2) M8 × 25 mm Screw








(4) M8 Washer, 5mm thick





(2) M8 Stud


1:1 Scale


Recyclable where facilities exist




































www.poly.com/support/studio-e70





